



4819C 48 Ave., Suite 286, Red Deer, Alberta T4N 3T2
Phone: (403) 314-1322 Fax: (403) 314-1320 e-mail: support@iiiisoftware.com
www.iiiisoftware.com

IMPORTANT COMPUTER SECURITY ANNOUNCEMENT

March 15, 2010

RE: Energizer Battery Chargers

Dear Visual-Eyes[®] clinic:

It has recently come to our attention that there is an issue with the software installed for the Energizer battery chargers. After installation, the software can create a security vulnerability that would allow an attacker entry into your computer; giving them remote access to files and applications.



Please uninstall the Energizer software, and delete the file called **arucer.dll** from your Windows system32 directory, then restart your computer. Please contact your computer maintenance person if you are unfamiliar with this process. Additional protection may be required, such as blocking port 7777/tcp on your router or firewall. For more information please visit the website www.energizer.com visit the Media Center/Press Releases, there is a document dated 03/05/10.

To safely use the battery charger do not connect it to your computer, please use the power adaptor to plug it into a wall outlet and charge your batteries.

If you have any questions or concerns about this document, or require any other assistance, please contact Visual-Eyes[®] Technical Support at the phone or email address provided in the header of this document.

Sincerely,

Visual-Eyes[®] Technical Support